



## TENANT DIRECTIVE

MTN: 200.7

Date: June 17, 2014

TITLE: Procedures for Movement & Non-Movement Areas.

I. References:

- A. Code of MD Regulations (COMAR) 11.03.02.04 Control of Vehicular Traffic.
- B. This Directive supersedes Martin State Airport Tenant Directive 200.7, dated April 1, 2014.

II. Definitions:

- A. Air Operations Area - any area of the airport used or intended to be used for landing, taking off or surface maneuvering of aircraft.
- B. Movement Area - runways, taxiways, helipads, & other areas within air operations area of the airport that are used for the taxiing, takeoff & landing of aircraft. At MTN, the movement area is further defined as Runway 15-33 and Taxiways A, B, C, D, E, F, T, J, S and the South Helipad located 300' east of Hangar 6.
- C. Non-Movement Area - that area uniquely depicted on Attachment 1.
- D. Aircraft, pedestrians and vehicles.
- E. Authorized Vehicle - a motor vehicle which has been granted prior written permission by airport management to access the movement area.

III. Directive Statement:

- A. Compliance with this Directive is mandatory for all traffic at Martin State Airport.

Martin State Airport  
701 Wilson Point Road – Box 1 – Baltimore, Maryland 21220-4282  
Telephone: (410) 682-8800

IV. Procedures:

A. Operations in/on the Airport Movement Area.

1. Communication with the Control Tower is mandatory when operating an aircraft/vehicle on any portion of the designated movement area.
2. A person may not drive an authorized motor vehicle on or across a runway, taxiway, or helipad unless that person maintains 2-way radio communication with and receives clearance from the Control Tower. If the vehicle is not equipped with an operable 2-way radio which operates on the airport's ground control frequency, that vehicle may only enter upon a runway, taxiway or helipad under the escort of or by the instructions of another authorized motor vehicle which is equipped with 2-way radio and which is in contact with the Control Tower.
3. Vehicles without 2-way radio equipment capable of operating on the Control Tower's ground control frequency but which are permitted to operate on the movement area by visual reference to light signals from the Control Tower may not proceed any closer than 200' from the edge of any runway or taxiway without approval from the Control Tower. It shall be the responsibility of all vehicle operators to recognize and understand the standard light signals used by the Control Tower.

B. Operations in/on the Airport Non-movement Area

1. Movement of aircraft or vehicles on airport non-movement areas is the responsibility of the pilot/aircraft operator, or vehicle operator.
2. Radio communications with the Control Tower are NOT required by aircraft/vehicles being operated totally within the non-movement area except those aircraft intending to taxi to the active runway for departure.
3. Any communication by the Control Tower with aircraft/vehicles in non-movement areas shall be advisory in nature, and should not imply ATC separation.

ELECTRONIC COPY  
ORIGINAL ON FILE IN AIRPORT OPERATIONS

Al Pollard, A.A.E., Director,  
Martin State Airport

Attachment

